

Operating Instructions



Warning!

Misuse of IntelliSteer may result in injury or death.

- ⇒ Do not use IntelliSteer when travelling at speeds greater than trolling speed.
- ⇒ Be sure area around helm unit and pendant is clear of people and obstacles before using.
- ⇒ Connect drive unit to 12v DC power supply only.
- ⇒ Only use IntelliSteer if there are no other boats nearby.
- ⇒ Do not allow children to operate IntelliSteer.
- ⇒ Turn the power off when not in use.

How to Operate...

- 1) Turn on breaker to supply power to the drive unit.
- 2) Plug in pendant.
- 3) Press the "ON" button located on the pendant (LED will illuminate)
- 4) To steer the boat left, press the left arrow button.*
- 5) To steer your boat right, press the right arrow button.*
- 6) To turn unit off, press "OFF" button.

③ Power ON

⑥ Power OFF

* Steering occurs only when jog buttons are fully depressed.

